



## **GENERAL 'GOOD PRACTICE' SUGGESTIONS PRIOR TO GLUING TUBULARS**

Tubulars require a little attention prior to gluing and mounting.

It is important to mount and inflate the tubular to 8 bars for a minimum of 12 hours.

This process allows the tire to stretch and regain its shape before gluing (after it has hung in a shop and priorly been shipped and/or packaged).

In this phase you must make sure the tubular is centered on the rim and confirm the round shape before deflating.

Where the tubular were not aligned properly, deflate the tubular and align it, balancing the view of the slight exposure of the base tape on both sides of the rim.

Re-inflate the tire and leave for 12 hours before gluing the tubular.

This operation will help you mount the tubular more easily during final gluing and assure proper alignment and roundness of the tubular during the life of the tire.